

Light Operation:

LED light runs on 3 AAA batteries.

Turn on the LED light by pressing the ON/OFF button on top of the light. Hold the button for 5 seconds to shut it off. There are 9 different sequences. Access to batteries by removing 2 bottom screws on light. Light cover splits in half leaving lower portion attached to frame.

Set-Up:

Turn the tip-up upside down and pull outward on the opposite legs. **Turn light on before setting spring.** Surround the base of the tip-up with snow to prevent the ice hole from freezing.

Size:

Easily covers a 10" hole

NO MORE TANGLED TIP-UPS!

Storage:

Lower hook to light base magnet when finished (see fig. 1). Collapse legs of the tip-up and tuck fabric in a circular motion to close.




fig 1



Video Instruction

*Full video instruction available
on our website*

www.firehouseproductsllc.com

